

Mass Storage mode.

Hold down the WiFi and shutter buttons while you plug in the USB cable to enter Mass Storage mode. It is Acrobatic Gesture



On mac you docent see hidden folders type .trash that are created by i Photo or Images but with a application called MacPilot you can access hidden folders in this mode You can also reach the storage in the Disk Utility app




In Disk Utility app you can erase or format the storage when in **Mass Storage mode** But when You stand in the RICOHDCX katalog or folder try to press **cmd+shift+g**



Go to the .trash folder if it exists and erase its content You should use the in build **Image Capture app on a Mac** to import and erase images from a THETA not the IMAGE or i Photo application





Regards Svendus